

Selectronix, Inc.
16419 199th Court Northeast
Woodinville, Washington 98077-5401

(425) 788-2979

FAX: (425) 788-7376

ProtoNodeFieldUpgradeProcedure

Equipment Required:

1. Laptop PC configured with static IP address of 192.168.0.102
2. Power supply, 24V dc

Procedure:

1. Connect 24V power to the ProtoNode
2. Connect the laptop to the ProtoNode using a straight-through cable.
3. Using a browser, enter 192.168.0.103 and see the Sierra Monitor screen
 - a. Locate the configuration file sent from Selectronix xxxxxxxx.csv
 - b. Upload this file to the unit:**
 - i. Select <Diagnostics & Debugging> on the home page
 - ii. In the Navigation pane, select <Setup>
 1. Select <File Transfer>
 2. Select <Choose File> and select the applicable configuration file
 3. Select <Submit> and see various status messages, then “Configuration update complete...”
 - c. Restart the system**
 - i. Select <System Restart>
4. If you have any other issues with the ProtoNode settings, free technical support is available from ProtoConvert
 - a. By email:
 - i. support@protoconvert.com
 - b. By phone
 - i. USA/Canada (Toll Free) : +1-888-793-0418 Ext 2
5. If you have any other issues with the data points, contact Selectronix
 - a. By email
 - i. techsupport@selectronix.us
 - b. By phone
 - i. (425) 788-2979